

SOP - Cooling fans

- Cooling fans are controlled by computer in each house and set by the company chart each phase during the turn.
- If malfunction is suspected, lower thermostat to visually see proper operation and replace/repair as necessary.
- Temperature charts are kept in each barn.

Note: Computer located in the middle of each barn-center wall controls all ventilation aspects. They are set by chart, by day occupied. Back up ventilation in the event of power failure is preformed by hired hand curtain controllers that drop the curtains when the temp. Exceeds a setting, usually 100 degrees. Thermostats for the hired hands are located on the inside walls- (north and south of buildings) opposite the externally mounted hired hands.